



AS4MICRO Portable simultaneous li-ion battery charger

User Manual

WE STRONGLY RECOMMEND THAT YOU READ THIS INSTRUCTION BEFORE USING YOUR BEBOB AS4MICRO CHARGER! PLEASE KEEP THIS MANUAL FOR FUTURE REFERENCE

Features

- 4 Channel Amicro (Gold-mount compatible) simultaneous Li-Ion Charger.
- Built-in AC Adapter. 16,5V 5.0A DC XLR4 Output

Charging

- All Channel Status indicator show green when the charger is turned on with no battery connected
- The Channel Status indicator turns red when a battery is placed on the corresponding channel and the charging process has begun
- The Channel Status indicator turns back green when the battery is fully charged
- The Channel Status indicator turns Yellow when a battery is placed on the corresponding channel and the charging process fails for damage or safety reason.
- Cooling fan will be activated during the charging process

AC Adapter

- You can use your AS4micro either as an AC Adapter or as a charger. Both functions aren't possible simultaneously
- The charging functions always has priority
- The AC adapter delivers up to 5,0A under 16,5V

bebob factory GmbH – Höglwörtherstr. 350 – D-81379 München – Tel.: +49 89 27818282 www.bebob.de

Safety instructions

• Only for professional use! Keep Charger out of reach of children and personnel that has not been instructed in the use!

pepor

- Use only with recommended batteries.
- Keep the charger dry and do not immerse in water.
- Do not cover the charger under use
- A standard three-pin AC plug must be used and earth pole must be connected to the earth line.
- Do not keep in contact with any part of the body while the charger is in working status.
- Do not use or store the charger in unstable, dusty or damp environments.
- Remove the battery from the charger after the charging process is complete.
- Do not attempt to open or repair the charger. Contact your dealer for help if it becomes defective.
- Handle with care! Do not throw! Do not drop!

Warranty

- The AS4micro is covered by a 2 years unconditional warranty on all parts.
- For warranty issues or if you have any additional questions, please contact the appropriate bebob distributor listed at <u>www.bebob.de</u>.

Specifications

Model	AS4micro
Mount	Amicro (Gold-mount compatible)
Channel	4 simultaneous
Charging current	16,8V 1,25A (per Channel)
DC Output	16,5V 5.0A
DC Port	XLR4 1 minus 4 plus
AC In	90-264V/47-63Hz 100W
Weight	1,0 Kg
Dimensions (WXHXD)	110 x 231x 141mm
Batteries	bebob
Charging time (bebob VS2/VS4)	depends on the battery capacity
Operating Temp. Range	- 10°C ~ + 35°C

bebob factory GmbH – Höglwörtherstr. 350 – D-81379 München – Tel.: +49 89 27818282 www.bebob.de