

PRECISION LIGHTING INSTRUMENTS



# 5-Light-kit (soft case)



Code: SPS5

Make work light Make light work Portable Studio -The Concept

The Portable Studio gives you all the power of dedolight's award winning lights in a package compact enough for even a one person camera crew. Comparable lighting kits from other manufacturers

can weigh three times as much, are more than three times the size and don't offer the same potential.

Elements of this lighting system are regularly used on elaborate Hollywood film productions (\$100 million blockbusters) and for intricate special effects sequences, such as on Harry Potter, Armageddon and Lord of the Rings.

It's no surprise that dedolight won two awards from the Oscar Committee of the Academy of Motion Picture Arts and Sciences and an Emmy from the Academy of Television Arts and Sciences.



# THE FOCUSING


# LIGHTS

Our revolutionary optical system uses two unique aspheric lenses.


The front lens is fixed, but the other moves either with the lamp and reflector OR relative to both the lamp and reflector (patented).

#### The 150 W light offers:

 More light output than a 500 W studio luminaire








# THE SOFT LIGHTS

### dedolights

- · Give a lot of light for a few watts beautiful light.
- Double the light output compared to the output of a soft box in front of traditional studio lights.
- Pleasant smooth light distribution with no hot spots. Perfect portrait – key light (see also page 12).



### EXTENDED REACH

Traditional studio luminaires of a comparable size offer a focusing range (change of intensity in the center of the lit area) of about 3:1. dedolight operates up to 25:1, giving it a much larger variation between flood and spot, higher output, and control that is more precise. This allows the professional to place the light further away, keeping it out of shot, while allowing people to move around the lit area with less noticeable change in intensity.

5



Flood



Medium



Spot

# BETTER LIGHT FOR

### Precision Lighting

- The dedolight distributes perfectly even light across the lit area in all focusing positions – without hot spots or bright rings.
- It also emits a pure beam with no stray light to offer the cleanest, most defined light beam. To soften the beam edges, fit any of 23 different diffusion gels. No filter or gel exists that can make an undefined light beam more precise.

### BETTER

### CONTROL

#### DBD8

No light source can offer cleaner shadow edges than our 8-leaf barn doors (due to our patented optical system).

#### **DLWA**

An optical wide-angle attachment with its own 8-leaf barn door for working in confined spaces, while retaining focusability, light distribution and barn door control.

#### **DLWAR**

Same as DLWA, but with rotating barn door leaves (patented) for vertical shadow edges when lighting from an angle.

#### DGRADF03/06/09

Graduated grey filters (on heat-resistant Borosilicate glass) offers smooth light distribution when lighting from an angle. Three steps of intensity: 0.3/0.6/0.9 for different angles of incidence or effects.

#### **DSCK SET**

Scrim sets consist of:

**DSCFS** (full single), **DSCFD** (full double), **DSCD1/2** (1/2 double), **DSCS1/2** (half single) and **DSCG** (graduated). (one each in DSCK set)

**DTCF** From tungsten to daylight **DTCF** From daylight to tungsten Dichroic conversion filters.

#### **Gel Sets**

Cut to size for our filter holders, or larger, to be clipped on to the front of our barn doors: diffusion, blue, effect colors and warm tone filters.







DLWAR



DGRADF03, DGRADF06, DGRADF09



DSCD1/2





















DPGSET

# DP2







DPLZ120M DPLZ150M





DPL185M

DPX





DPL60M

DPL85M

#### DP1

DP1 including 85mm projection lens The DP1 Universal Projection Attachment/Imager works with:

#### **DPFS**

Framing Shutters – Moveable masks for precision light and shadow forms.

#### **DPIR**

Iris

#### **DPGH** Gobo Holder

**DPGSET** Gobo Set - 6 pieces.

#### **DPACP**

Accessory pouch for gobo, scrims, etc.

#### **Gobo Projections:**

Our steel gobos are available in more than 300 different shadow patterns (see gobo catalog), while the range of glass gobos available include multicolored and made to order variations. Gobo sets for DP1 need DPGH Gobo Holder.

#### DP2

DP2 including 85mm projection lens
The DP2 Projection Attachment/
Imager is the same as the DP1, but
with integrated framing shutter leaves
which are easier to adjust (not suitable
for iris or gobo projection).

All Projection Attachments/Imagers use interchangeable lenses. These precision optics include seven different focal lengths, covering wide angle, standard, telephoto and zoom.

#### DPLZ120M

Zoom 70 - 120mm

#### DPLZ150M

Zoom 85 - 150mm

#### DPL185M

Projection lens 185mm

#### DPL60M

Wide-angle lens 60mm

#### DPL85M

Standard lens 85mm (included with DP1 and DP2)



The optics of these attachments have been carefully designed to match the dedolight double aspheric system (when used on other light sources, they will show inferior results). They offer highly precise light and shadow edges without:

- Color fringing
- Halation
- Distortion

...which plague other comparable systems in a variety of combinations.

# PROJECTION/IMAGING SYSTEMS

- Create interesting background projections with gobos (for example during interviews), with otherwise dull backgrounds.
- Create the most precise effects and accents down to the smallest detail.

## Projection Systems

## MAGER

### THE DP1 - UNIVERSAL-IMAGER USES

- To create interesting background projections with gobos (for example during interviews), with otherwise dull backgrounds.
- To create a specific mood in your images, such as with large projections on the entire background.
- To place high precision accents or effects on your product shots, even for the smallest conceivable objects (i.e. select facets of a diamond may be specially lit). This can be done with a combination projection lens and extension tube.
- To give a video interview a "film look." Almost all video cameras use lenses that deliver an extended depth of field compared to those used with film cameras due to their small sensor area in relation to the larger film image. The result: the background remains in focus. There is no separation from the background as you would get with the more limited depth of field of a film camera.

An out of focus background projection created by one of dedolights DP1 imagers cannot be put back into focus by any video camera. This provides better separation between foreground and background, and gives the impression of greater depth – the magic of image creation.

### Background-Effect-Filters

Use with DP1 Imager

Five different structures in eight colors create miracles for your background.

Amazing change of shapes and moods when changing sharp projection to "out of focus".

All Effect Filters are available in: Blue (B), Purple (P), Light blue (LB), Red (R), Magenta (M), Yellow (Y), Turquoise (T), Light green (LG).

Order code example:

DFXT6-B = "Mystic Squares" in blue

Can be combined (sandwiched) with steel gobo patterns.









Effect Glass Holder



DFXT4 Effect Glass "Waves"



DFXT6 Effect Glass "Mystic Squares"



Effect Glass "Crystal"



Effect Glass "Flow"



Effect Glass "Cells"

# DEDICATED SOFT LIGHTS

Every portable studio should include one or two soft lights.

The dedicated dedolight soft lights do not work like the usual soft box attachment in front of a studio light. Such traditional versions are large and unwieldy and offer only a limited light output.

How it should **NOT** look: with a hot spot.



Worst of all, they usually show a hot spot

in the center of the diffuser; totally contrary to the basic concept of a soft light as a "wrap around" light source.

dedolight soft lights are designed to achieve the best possible soft light, and currently come in 11 different versions: 7 tungsten systems and 4 interchangeable daylight/tungsten systems.

- You get an even soft light, with no hot spots, because the light source sits at the focal point of the textile reflector.
- They have a higher light output (two times). The front diffuser is completely evenly lit.
- Extendable patented holding arms for the rods of the soft boxes allow the use of soft boxes of various sizes in order to adapt the character of the light and the transparency of the shadow borders to the distance from the object (one person/several people).

The very small, dimmable DLH1x150S mini has a light output equal to a soft box in front of a 500 W studio light, making it the perfect choice for the portable studio. All dedolight soft lights have unique characteristics that make them particularly flexible and creative lights – right up to a DLH4x150S unit that can be tuned to give you just the light you want, up to the equivalent of a 2 kW Fresnel fitted with a soft box.



# PanAura® 5 • Octodome

### THE PORTABLE WINDOW

The PanAura® 5 is the largest of our 11 soft lights. It gives extremely smooth light distribution. With its minimal depth, the PanAura® 5/ Octodome does not protrude into the room further than the leg of the stand. Its shallow, easily set up construction is perfect for working in confined areas. If adding the optional grid (40° louver), the professional can retain the large smooth diffuser surface but give it distinct direction and keep the spill light away from the background.



#### SPA5DT-S (DSOCTDT400)

Tungsten/Daylight Kit standard:

1 DLH400SDT 400/575W daylight/tungsten soft light head

1 DEB400DT electronic ballast 400/575 W

1 DPOW400DT cable, light head to ballast, 7 m (23 ft.)

1 DEB400H ballast holder with clamp

1 HTP400S high temperature resistant pouch

2 DL400DHR-NB 1 400/575 W daylight lamp

(2 DL575THR-NB 2 400/575W tungsten lamp

1 DLPA5 (DSBOCT) PanAura® 5 (Octodome 5 feet)

1 DLPA5G (DLGRIDOCT) PanAura® 5 (Octodome)

grid (40°)

1 DST400S stand

1 DSCPA5 (DSCOCT) soft case

Size: 94 x 37 x 21 cm / 37" x 14.6" x 8.3"

Weight: 12.5 kg / 27.6 lbs

1 Lamp each plus spare

2 High output 575 Watt – Tungsten discharge lamp; perfect color rendition; fully compatible with the daylight lamp; same ballast; same light output, 4 x higher than halogen (available soon).

#### SPA5T-S (DSOCTT-S)

Tungsten Kit standard:

1 DLH1000SPLUS 1000 W tungsten soft light head 1 HTP1000S high temperature resistant pouch

2 DL1000FEL-NB lamp 120 V/1000 W

1 DLPA5 (DSBOCT) PanAura® 5 (Octodome 5 feet) 1 DLPA5G (DLGRIDOCT) PanAura® 5 (Octodome) Grid (40°)

1 DST400S stand 1 DSCPA5 (DSCOCT) soft case

Size: 94 x 37 x 21 cm / 37" x 14.6" x 8.3" Weight: 9.2 kg / 20.3 lbs

# 3-Light Kit





1 DLH1x150S soft light head, 150 W tungsten
1 HTP150S high temp. resistant pouch
1 DT24-1U power supply, 150 W/24 V
1 DSBSXS dedoflex mini soft box

2 DLHM4-300U light head with built-in transformer

2 DPLS light shield ring
2 DBD8 barn doors
1 DLTFH dedoflex holder
1 DFT30 diffuser, translucent

1 CLAMP1 clamp 1 DH2 wall holder 3 DST stand

1 DSTFX flexible stand extension

2 DL150-NB halogen lamp 150 W/24 V, clear

4 DL150 halogen lamp 150 W/24 V, black tipped

1 DSC1/1-200 soft case

Size: 65 x 23 x 30 cm / 25.5"x 9.1"x 11.8"

Weight: 12 kg / 26.5 lbs

SPS3

# QUICK AND EASY

For many small mobile teams, it is not only important to work effectively and offer the best possible quality, but also to work on a deadline.



To help achieve this, dedolights can be set up faster and easier than any others.

Typically, the biggest delay comes at the end of the shoot, when light heads are hot, making "tear down" difficult. With dedolight's heat resistant pouches, made with ceramic textile space technology materials, mobile professionals can quickly pack the hot light heads from the soft lights without any delay. There is no problem packing the focusing light heads while still warm.

# How To LIGHT WITH THE 3-LIGHT KIT




# SET UP IN 15 MINUTES OR LESS.

The same time period applies for the set up of the 5-light kit.







# THE MOST ECONOMICAL SYSTEM —

### OPERATIONAL COST

With the exception of the 1000 W soft light (DLH1000S) all of the other light sources described here are low voltage lights (24V/150 W).

#### THE ADVANTAGES:

 LIGHT OUTPUT – Apart from the distinctly higher light output provided by our revolutionary optical system, our 24 V lamps provide 40 lumen per watt in comparison to standard halogen lamps, delivering just 20 lumen per watt.

The dedolight low voltage system offers comparable light output to a traditional 500W studio light source.

 LIFETIME – Traditional halogen lamps for 3200 K are usually described as having a life expectancy of 150 hours.

When used at 3200 K the dedolight lamps run approximately 600 – 800 hours. Even using maximum voltages at 3400 K, we still reach approximately 120 hours.

Traditional halogen lamps are very susceptible to vibration and shock, so mobile teams rarely ever reach the quoted lifetimes.

 INDESTRUCTIBLE – dedolight lamps are extremely resilient when subjected to hard knocks and vibration. In practice they achieve many times the life of traditional high voltage lamps.

OUR LOW VOLTAGE LAMPS COST LESS THAN 1/4
OF COMPARABLE HIGH VOLTAGE LAMPS.

## Unbreakable

dedolights have proven to be extraordinarily rugged and dependable under the toughest circumstances.

The highly developed double aspheric system is not only compact, but able to stand up to the toughest tasks (Dedo's experience in more than 40 countries pays off).

Transport: Do not hesitate to check in your kit at the airport. Although some baggage handlers are masters of destruction, you will arrive at your destination with functioning gear and no broken lamps.

AND, the painful charges for excess baggage will result in much lower rates than you are accustomed to.



### MORE LIGHT IN THE SMALLEST PACKAGE

MAGIC IN A BOX



# 5-LIGHT KIT



#### SPS5

2	DLH1x150S	soft light head, 150W tungsten
2	HTP150S	high temperature resistant pouch
2	DT24-1U	power supply, 150 W/24V
1	DSBSXS	dedoflex mini soft box

1 DLGRIDXS mini grid

1 DSBSS dedoflex silver dome, small

1 DLGRIDS grid, small

3 DLHM4-300U light head with built-in transformer

3 DPLS light shield ring
3 DBD8 barn doors
3 DFH filter holder

1 DGW gel filter, warm tone 1 DGMB gel filter, mixed blue 1 DGMD gel filter, diffusion 1 DGCOL gel filter, color effect

1 DSCK scrim set 1 DSCP scrim pouch

1 DP1 projection Attachment/Imager

1DPGHgobo holder1DPGSETgobo set1CLAMP1xlamp

1 DSTFX flexible stand extension

5 DST stand

2 DLBOX plastic box

4 DL150-NB halogen lamp 150 W/24 V, clear

6 DL150 halogen lamp 150 W/24 V, black tipped 1 DSC2/2-200 soft case

Size:  $83 \times 30 \times 33 \text{ cm} / 33" \times 11.8" \times 13"$ 

Weight: 20 kg / 44 lbs

# NEW BACKPACK OPTION FITS ALL PORTABLE STUDIO KITS WITH THE EXCEPTION OF THE 6-LIGHT KIT.

#### To carry:

Easy, comfortable, ergonomic top quality adjustable shoulder and belt straps with two handles.

#### To pack:

Adjustable inner dividers offer protection, easy handling and balanced weight distribution.

#### To ship:

Shoulder and belt straps disappear in the zip-up kangaroo pouch. Backpack can be checked in as luggage without worrying about airport baggage handlers who have a talent for destroying equipment.

#### To store:

Made with top quality materials and components to protect your equipment.

Size: 70 x 50 x 30 cm / 27.5" x 20" x 12"

Weight:  $4.5\,\mathrm{kg}\,/\,10\,\mathrm{lbs}$ 



# How To Light


# AN INTERVIEW





# SET UP IN 15 MINUTES.

Light one person, or many, for an interview or portrait with the same kit.











### KEY LIGHT

We recommend a dedolight DLH1x150S soft light fitted with a small dedoflex dome (DSBSS) and louver grid (DLGRIDS). The dedolight soft light system offers unique, smooth and even light without hot spots on the diffuser, as you would find when using traditional soft boxes on the front of studio lights.

With all dedolight soft lights, the actual light source is in the focal point of the textile reflector. This is how we achieve double the light output in comparison to soft boxes in front of a studio light. In addition, this soft light features a glass reflector, which further heightens the light output and improves the light distribution.



### FILL-LIGHT

A 150 W dedolight soft light (DLH1x150S), with a mini soft box (DSBSXS) and 12" x 12" ( $30 \times 30 \, \mathrm{cm}$ ) diffuser. This light has been used in several major Hollywood film productions (often exceeding \$100 million budgets) as a portrait light for some of the world's best-known actors.

Depending on the end use (film/TV/photo) and on the desired character of the image, one can opt for a ratio of 1:2 between the key light and fill light (TV) or a higher ratio for film lighting that is more dramatic. The dedolight DLH1x150S soft light when used with the DT24-1U in-line power supply/dimmer is switchable to 3400 K, 3200 K and fully dimmable.

# **3** BACKLIGHT

The backlight should separate your subject from the background and help create a seemingly 3D effect and the illusion of depth. The unique character of the focusing dedolight DLH4 allows for the fine tuning of the backlight with utmost precision. A slightly cooler color temperature is often desirable for the backlight. This light can be set for a color temperature of 3400 K without using any filters.

Because of its enormous focusing range and the various control accessories, it is possible to partially lower the intensity for defined areas of the image should they otherwise be too bright (contrast ratio), or to place defined accents on darker areas of the image.

The clean beam, without any stray light, can avoid unintended light in the camera lens. Focusing, scrims and dimmability allow such effects to be fine tuned so that they can add to the image creatively without being obvious. Subtlety is the key. The flexible stand extension allows you to place the light source closer to the subject without the lighting stand being in the shot.

# 4 The Kicker -

### THE CONTROL LIGHT

This can be placed on the unlit side of the face to give heightened plasticity and dimensionality or modeling. As with the backlight, being able to precisely tune the intensity of the lit area and color temperature is key.

# 5 The Background Light

Use the louver/grid on the key light in order to keep unwanted stray light away from the background – this way you don't lose control over this very important image detail.

#### Two Variations:

- a) Using the focusing DLH4 light head for the background, professionals can choose the desired intensity for the background. With barn doors, half scrims or graduated scrims, you are able to create a light and shadow form that suites the desired image. The dimmability, diffusion, warm tone or effect gels help to create the desired mood, without detracting from the subject.
- b) With the DLH4 light and DP1 imager attachment our background effect filters (page 10 and 11) open up a world of creative effects and moods.

You are able to project shadow patterns (gobo), such as leaf patterns, venetian blinds, window shadows, abstract or neutral patterns, etc. There are over 300 different gobo patterns to choose from.

You can even combine our background effects filters with the steel gobos.

By defocusing (changing the focus position of the projection lens until the projected image is out of focus), you are able to create the impression of greater depth and so separate the subject from the background and create the "film look." In a feature film, shot on 35 mm film, this look can appear natural by the selective depth of field of the longer focal length lenses used.

With a video camera and its much smaller sensor, the same image size (angle of view) is achieved with much shorter focal lengths, which will also leave the background in focus. No video camera can put an out-of-focus projection back into focus.

For interviewing two, three or more people, you can put a medium size soft box on the key light, and the small size soft box on the fill light, or cross light with two matched key lights, plus two matched back lights.



# Useful extra equipment

### AND MOUNTING \_ DEVICES

#### CLAMP1 (1)

#### dedolight clamp -

The dedolight clamp attaches securely to stands, pipes, shelves, etc. It is fitted with a 16 mm (5/8") stud that pivots and locks in two positions.

Weight: 147 g (5.2 oz.)



#### dedolight flexible stand extension -

Works with DST stand, CLAMP1, or any 16 mm (5/8") stud. It can be bent in any direction, even S-shaped. Particularly useful to position a backlight on a lighting stand, which might otherwise be visible behind your interview subject. Bend it twice so that the stand can be moved further out of picture. Connect the soft case with a cable tied to the stand as counterweight.

(1) CLAMP1 and DSTFX are included in all PS kits.

#### **DLTFH**

#### Flexible arm with three clips -

Holds dedoflex 30 cm (12") translucent diffuser. Mounts between light head and stand. Converts focusing light to a soft light source.

#### DFT30

translucent dedoflex Ø 30 cm (12")

#### Set DLTFH/DFT30

included in SPS3

flexible holder - mounts between light head and stand. Includes foldable translucent diffuser (DFT30). Converts focusing light head to a soft light source.



#### wall holder

Made of special elastic aircraft aluminium, the dedolight holder not only tapes to flat surfaces but cutouts in the plate allow it to be attached to table legs and small or large pipes. Use the supplied mounting chains or gaffer tape, nails or screws. Weight: 142 g (5 oz.)







4-Light Kit (Backpack)





Code: BPS4

#### BPS4

2	DLH1x150S	soft light head, 150W tungsten
2	HTP150S	high temperature resistant pouch
1	DLHM4-300U	light head with built-in transformer and dimmer
1	DLH4	light head
3	DT24-1U	dimmable electronic in-line transformers

1 DSBSXS dedoflex mini soft box, silver

1 DLGRIDXS grid, mini

1 DSBSS dedoflex silver dome, small

1 DLGRIDS grid, small
2 DPLS light shield ring
2 DBD8 8-Leaf barn door
1 DSCK scrim set

1 DSCP scrim pouch 1 DP1 projection Attachment/Imager

1 DPGH gobo holder 1 DPGSET gobo set

DCAR3 adapter cable for car cigarette lighter
 DXBAT4-3 battery cable with 4-Pin-XLR connector

4 DST stand

1 DSTFX flexible stand extension

1 CLAMP1 clamp 1 DH2 wall holder


4 DL150-NB halogen lamp 150 W/24 V, clear

4 DL150 halogen lamp 150 W/24 V, black tipped

2 DL100-NB halogen lamp 100 W/12 V, clear

DLBOX plastic box
 DBP backpack
 Size: 70 x 50 x 30 cm/27.5" x 20" x 12"

Weight: 18.7 kg / 8.5 lbs




# THE DAYLIGHT CHEAT

Many interior scenes have to accommodate daylight. **Focusing** dedolights can be used with a dichroic daylight conversion filter (DDCF – light loss one stop) leaving enough light intensity for backlight and kicker.

For background effect projections the light level with this filter may be limited: reduce size of projection area or create a background effect without imager/projection.

For **SOFT LIGHTS** the "cheat package" offers blue and half blue diffusers (loss with full conversion: two stops).

How to handle this situation?





- <u>OR</u>-use "half conversion" and set white balance according to area lit by half conversion. This will render the image areas lit by pure daylight in a somewhat cooler way. Quite acceptable in many cases.
- <u>OR</u>-use the incoming daylight as key light because the fill light soft light needs less intensity.
- <u>OR</u>-in the 5-light kit, replace one of the two soft lights with a DLH1000S dedolight soft light with medium soft box, which will allow a larger area to be lit.
- A DLH1000S soft light 1000 W
- DSBSM
   soft box, medium with white diffusers (shown with optional blue front diffuser)
- © **DLGRIDM** Grid 40°



#### Daylight Conversion Package for:

#### 3-Light-Kit: SPS3-DAYCON

2 Dichroic filters, half blue and full blue diffusers

#### 4-Light-Kit (Backpack): BPS4-DAYCON

2 Dichroic filters, half blue and full blue diffusers

#### 5-Light-Kit (Standard): SPS5-DAYCON

3 Dichroic filters, half blue and full blue diffusers

#### 1000W Option for 5-Light Kit: SPS51000-DAYCON

Instead of one of the soft lights (DLH1x150S and soft box small, grid small, power supply, lamp, pouch) usually contained in this kit, use 1 DLH1000S soft light complete with medium soft box (DSBSM), grid, white, half blue and full blue diffusers. Additional extra blue diffusers for the remaining mini soft light, plus 3 dichroic daylight conversion filters for the focusing lights, pouch and lamp 1000 W.

#### SEPARATE 1000W Option: SEP1000-DAYCON

In addition to the 5-light kit with the SPS5-DAYCON package, 1 extra DLH1000S soft light, pouch, medium soft box with white, blue and half blue diffusers, grid, lamp 1000 W, stand and soft case.

### FOR MIXED LIGHT (DAYLIGHT AND FLUORESCENT LIGHT)

Correcting diffusers are in practical testing.

### SUNDANCE

DLH200DT

If your work includes daylight situations more often and you also want to work with more intense daylight, this is your best choice:

### THE ONLY DAYLIGHT AND TUNGSTEN LIGHT KIT

#### S200-3

2

1 DLH200SDT 200 W daylight /tungsten soft light
2 HTP200S high temperature resistant pouch
3 DPOW200DT cable, light head to ballast, 7 m (23 ft.)

3 DEB200DT flicker-free electronic ballast, 200 W (90-260 VAC)

200 W daylight/tungsten light head

3 DEB200H ballast holder with CLAMP-C 1 DSBSM dedoflex silver dome, medium

2 DBD8
2 DPLS
2 DTCF
4 Seleaf barn door
2 light shield ring
5 tungsten conversion filter

3 DL200DHR-NB 200 W daylight lamp

1 DL200THR-NB 200 W tungsten ceramic lamp

3 DST stand 1 DSC2/2-200 soft case

Size: 83 x 30 x 33 cm / 32.7" x 11.8" x 13"

Weight: 20 kg / 44.1 lbs



### 1. Precision Focusing - DLH200DT

- Fantastic light output and focusing range beyond any comparable system
- Surgically precise beam
- · Perfectly even light distribution
- Accepts all classic dedolight accessories and imagers



### 2. GENTLE SOFT LIGHT - DLH200SDT

- Single purpose dedicated design
- The actual light source is in the focal center of the soft box
- Double the light output compared to soft box in front of a Fresnel
- Smooth and even light distribution on the diffuser
- Choice of many different sizes of soft boxes



### **BOTH LIGHTS**

Convert from daylight to tungsten by simple lamp change—maintaining same high light output 80 lm/W – four times higher than halogen. Both lamps guarantee professional color rendition CRI >92.



Works with daylight and tungsten lamps.







### **A**CCESSORIES:

# LEDZILLA® / FILLINI®

#### DLOBML-XLR

connector ALX niq-4 diw "LB - BS Coiled cable 65 cm - 1.30 m/



### DLB-NPF550 (4)

(AAm 000S) 7.2 V Li-Ion battery 14.8 Wh



### **DLOBML-SWIT**

 $0.1/5.5~\mathrm{mm}$  connector Cable 55 cm/22" with



### DFB-NbE920 (4)

(dAm 0008) 7.2 V Li-Ion battery 43.2 Wh



#### DLOBML-PAG

for PAG battery & 2.1/5.5 mm connector Cable 55 cm/22" with


Cable 1.8 m (6 ft.) with



Input: 100-240 V~

DCH-NPF (4)

Charger for NP-F batteries



Bauer connector Cable 22 cm/9" with Anton/



### DLOBML-P

connector cigarette light

**DLOBML-CAR** 

Soft pouch for LED lights



#### DLOBML-AB-L

Bauer connector Cable 55 cm/22" with Anton/





# Accessories:

# LEDZILLA® / FILLINI®

#### DLPS-12

with DC 12 V output Mains power supply (100-240V)



#### DLOBML-BC

for BP-9 7.2 V Canon battery shoe



#### DLOBML-BP

904s V Panasonic battery shoe

for CGA

**DLOBML-BP2** 

for VWW-VBG6 (AG-AF101) 9012 V Panasonic battery shoe

DEOBME-BSU

**DLOBML-BS** 12 V Sony battery shoe for BP-U

7.2 V Sony battery shoe for NP-F /

**DLOBML-PBN1** Panasonic VW-VBD1

EN-EF3E Nikon photo battery shoe for

**DLOBML-PBC1** 

**LP-E6** Canon photo battery shoe for



VZ.1 seiresta External battery box for 8 AA



### DLBSA-U (2) (3)

ends in male shoe Square top fits Ledzilla®,



### DLBSA-3S (4)

Triple shoe with tilt lock



#### DLA-LB

1/4" screw to camera with receptacles. Mounts shoes and 3 x 1/4" Large Bone, 2 x female

### DLBSA-MBJ

Metal ball joint with shoe



#### DLA-ML

("8/d) buts 16 mm baby Ledzilla®. Accepts Square top fits





## Accessories:

# LEDZILLA® / FILLINI®



with handle Shoe adapter



### DLGA300 (4)

Square top, Articulating arm, 300 mm.

male to camera male shoe or 1/4"

### **DLGA200**

light head

DLBRS (4)

and shoe for screw for camera

Rail with 1/4"

.mm 002 Articulating arm,



, "6.0x "8.2 x "7.8 Table shoe: 9.5 x 6.3 x 1.2 cm/



DLBSA-S (4)

1/4" male Female shoe adapter to



### DLBSA-T (4)

1/4" female Female shoe adapter to



### DLBSA-M (4)

DLBSA-T Sony mini camcorder, use with 1/4" male to mini shoe for



®inilli7 (1) Also suitable for:

(3) FILLINI Click® (S) FILLINIPLUS®

arm, 200 mm and articulating vacuum pump

suction cup with

DV3GA (4)

for light head 1/4" screw

Rail with folding DLBRHS (4)

handle,

bne sthgil ®inilli7 lle (4)

® Ellizb∋ 1



# \*Ashs INILITE


- with magnets. Unbreakable filters attach
- or in other configurations. Light heads stackable in a row
- for even light distribution. High efficiency reflector serves
- for Sony batteries. Battery compartment and shoe

#### With ball head/shoe TPSA-KAI Fillini Click® / TPLINI-C

### **BA-INIJ9T**

Anton/Bauer connector Cable 49 cm/19" with

Cables for all Fillini® lights are






Mains power supply

#### TP-KAI (4)

and 1/4" thread Ball joint head with shoe adapter





231 g .zo 8	mo 4.3 x 8.7 x 8.21 " 1.2 x 1.8 x 3	011	420	6
253 g 25.9 oz.	mo 0.3 x 0.0 x 6.01 " 2 x 3.5 x 2.4	195	008	Ţ2
3 LTL .50 8	mo	OΔ	300	9
[so\g] IngieW	Measurements [cm/"]	(MS) XUJ	Lux (1m)	[W] могтчмигио Сометиом [W]

### TECPRO®

### FILLINI® AND FILLINIPLUS®: Энт чо езяитаз иоммо

(tungsten conversion and light diffusion). Unbreakable flip-down filters

- Additional diffuser for even gentler
- light distribution.
- distribution. Fresnel lenses provide perfect light











**q-INIJqT \ ®≥ulq inilli**∃

FILLIMIPLUS® offers three times the light output of Fillini®

Shoe for Sony NP-F batteries TPLBS-S (1) (2)

**TPLBS-C** (1) (2)

Shoe for Canon BP-9 batteries

Shoe for Panasonic CGA batteries TPLBS-P (1) (2)

Battery shoes shown in table below.

Sony NP-F (non-removable)	V 8,81- 8,8	> AA Batteries > 3-9N you	<b>EILLINI</b> C⊔CK <sup>®</sup>
Sony NP-F Canon BP-9 Panasonic CGA	V 8,81 – 8,3		<b>EIFFINI</b> ÞΓ∩2⊚
Sony NP-F Canon BP-9 Panasonic CGA	V 21 - 4	4 AA Batteries	EIFFINI⊗
ВАТТЕВУ ЗНОЕЅ FOR	Вхтевиль Ромея	Питевия Ромея	

Power consumption is only 8 W

+ 40°C. Operates from -40° C up to

run time. accordingly resulting in twice the despite its high output. output, power consumption drops When dimmed to 50% light

lighter output or battery belt. Bauer or PAG system, car cigarette LED power available indicator. Alternative power from any Anton/

### CHINESE LANTERN OPTIONS: SOFT TUBE, SOFT BOX,

Attach by front end bayonet mount

#### DLOBML-LT20

plastic barn doors. Detachable light shaper-folding e.g., car interior at night. Ideal for soft light in confined areas, Soft tube, 20 cm/8" long -

#### **DLOBML-SBX12**

sten conversion filter. for close ups. Filter slot accepts tung-Gentle fill light, easy to look at, ideal - soft box, 12 cm/5" wide -

#### DLOBML-SBX12-CTO

Orange tungsten conversion filter

#### DLOBML-WD15

light with removable side flags. evenly distributed, ideal for general base White Dome, 15x15 cm, gentle light,

#### DLOBML-TCF

color effect. swatch book. Allows nearly any kind of serves for gel strips from any common of all three accessories. Same filter slot Tungsten conversion filter for filter slot





### - THOI J GARD LIGHT -

CODE: Drobwr

### тне рероцент Мім-DLOВ

comparable LED lights. distribution is cleaner than Color rendition and color

torward.

- it to be positioned above and Adjustable support arm allows
- zero without any color change. full blast all the way down to Dims extremely smoothly from
- bower source. Powers from any 6 V to 18 V DC
- mini-DV batteries. Panasonic, Canon and Nikon are compatible with Sony, Optional battery shoes
- Am 0002 ,V S.Y 0284-9N
- Am 0004, V S.Y 0273-9N 105 minute run time.
- 330 minute run time. . Am 0009, V S. Y 0294-9N 210 minute run time.
- 2.000 000.5 3.500

Flip-up wide-angle diffusor

Converts from daylight to

tungsten via a flip-down filter.

the wide angle diffuser in place. light and shadow transition with

door shadow OR a very gentle

· Clean, sharp, single edge barn

zero), without any color-change. from full power to minimum (not

Gentle continuous dimming

No other focusing LED light


with the dedolight double · Amazing output in combination

- Gal benewered LED -

lights are not usually focusable. Focuses like a dedolight. LED

compares - 4° to 56°.

aspheric optics.







# STHDIJ ED





48 Sheffield Business Park

info@dedolight.com

moz.tdelolight.com

info@dedoweigerthim.de ab.mlñtragiawobab.www

Fax: +49 (0)89 356 60 86 Tel.: +49 (0)89 356 16 01 doinuM √0808

Narl-Weinmair-Straße 10 Dedo Weigert Film GmbH

9552 677(814) əb.sllizbəl.www Phone: (413)229 2550 uə.oibutsəldetroq.www Ashley Falls, MA 01222